

Pair Your Remote with Your Adjustable Base

Instructions for Ease 3.0 models:

Please read the following steps before attempting the pairing because Step 2 is time-sensitive.

Step 1

Remove rear cover of the remote control by sliding it down to expose the PAIR button. Unplug the Power Cord from your power outlet. Wait 1 minute, then plug the Power Cord back into your power outlet.

Perform Step 2 within 10 seconds.

Step 2

Press and hold the PAIR button on the back of the remote. The PAIR button will illuminate and start to flash. When the PAIR button stops flashing, the LED light on the control box will stop flashing. Release the PAIR button.

Step 3

Test all remote functions. If the remote buttons do not impact the adjustable base movements, please repeat the process again or try the steps to Disable the Child Lock because the remote may be locked.